

LINETRAXX® CME420

Multi-functional current relay, AC, overcurrent/undercurrent/window discriminator function



LINETRAXX® CME420



Device features

- Undercurrent and overcurrent monitoring in AC systems 0.1...16 A
- Indirect current monitoring with standard current transformers x/5 A
- Transformation ratio n allows adaptation to all standard current transformers x/5 A
- Different monitoring functions selectable
 I, > I or < I/>I
- Start-up delay, response delay, delay on release
- · Adjustable switching hysteresis
- r.m.s. value measurement (AC)
- Digital measured value display via multi-functional LC display
- · LEDs: Power On, Alarm 1, Alarm 2
- Measured value memory for operating value
- · Continuous self monitoring
- Internal test/reset button
- Two separate alarm relays (one changeover contact each)
- N/C or N/O operation and fault memory behaviour selectable
- · Password protection for device setting
- · Sealable transparent cover
- Two-module enclosure (36 mm)
- Push-wire terminal (two terminals per connection)
- RoHS compliant

Approvals





Product description

The CME420 series current relays monitor undercurrent and overcurrent in AC systems as well as the current between two threshold values (window discriminator function). The currents are measured as r.m.s. values (AC). The currently measured value is continuously shown on the LC display. The measured value required to trigger the alarm relay is stored. Due to adjustable delay times, installation-specific characteristics, such as device-specific making currents, short-time current changes etc. can be considered. Current measurement is possible either directly or indirectly via standard current transformers (x/5 A). External supply voltage is required.

Typical applications

- · Current consumption of motors, such as pumps, elevators, cranes
- · Monitoring of lighting circuits, heating circuits, charging stations
- · Monitoring of emergency lighting
- · Monitoring of screw conveyors, e.g. in sewage plants
- · Dust removal in wood working

Function

Once the supply voltage is applied, the start-up delay begins. Measured values changing during this time do not influence the switching state of the alarm relays.

The devices provide two separately adjustable measuring channels (overcurrent/undercurrent). When the measuring quantity exceeds the response value ("Alarm 1") or falls below the response value ("Alarm 2"), the time of the response delays " $t_{on1/2}$ " begins. Once the response delay has elapsed, the alarm relays switch and the alarm LEDs light up. When the measuring value exceeds or falls below the release value (response value plus hysteresis) after the alarm relays have switched, the selected release time " t_{off} " begins. When " t_{off} " has elapsed, the alarm relays switch back to their original state (fault memory inactive). When the fault memory is activated, the alarm relays remain in alarm position until the reset button is pressed.


Standards

The LINETRAXX® CME420 series complies with the requirements of the device standards: IEC 60255-6.





Operating elements



- 1 Power On LED "ON" (green); lights when supply voltage is applied and flashes in the event of system fault alarm
- 2 Alarm LED "AL1" (yellow): lights when the set response value is exceeded or flashes in the event of system fault alarm
- 3 Alarm LED "AL2" (yellow): lights when the value falls below the set response value or flashes in the event of system fault alarm
- 4 Multi-functional LC display
- 5 Test button "T":

Arrow up button: to change the measured value display, move upwards in the menu or to change parameters.

To call up the self test: press the button "T" >1.5 s

6 - Reset button "R":

Arrow down button: to change the measured value indication, move downwards in the menu or to change parameters


To delete stored alarms: press the button "T" >1.5 s

7 - "MENU" button:

Enter button: to confirm the measured value indication or to confirm changed parameters

To call up the menu system, press the button "T" >1.5 s Press the ESC button >1.5 s to abort an action or to return to the previous menu level


Wiring diagram



- 1 Connection to the system/load being monitored
- **2** Supply voltage *U*_S (see ordering information)
- 3 Alarm relay "K1": configurable for <1, >1 or <1/>
 -1/ERROR/TEST
- 4 Alarm relay "K2": configurable for <1, >1 or <1/>
 -1/ERROR/TEST
- 5 Line protection according to IEC 60364-4-43:6 A fuse recommended. If being supplied from an IT system, both lines have to be protected by a fuse.



Timing diagram current monitoring



t - Start-up delay

 t_{an} - Response time

Operating time (t_{ae}) + Response delay $(t_{an 1/2})$

toff - Delay on release



Technical data

	l-3	
Rated insulation voltage	250 V	
Rated impulse voltage/pollution degree	4 kV/3	
Protective separation (reinforced insulation) between		
(A1, A2) - (k, l) - (11, 12, 14) - (21, 22, 24)	
Maximum rated voltage of the system being monitored		
(conductor to be monitored directly connected)		
With protective separation	AC 230 V	
Without protective separation	AC 400 V	
Voltage test acc. to IEC 61010-1	2.21 kV	
Supply voltage		
Supply voltage U _S	see ordering information	
Power consumption	≤ 4 VA	
Measuring circuit		
Rated frequency	42460 Hz	
Measuring range	AC 0.0516 A	
Overload capability, continuous	17.6 A	
Overload capability < 1 s	40 A	
Response values		
Undercurrent (alarm 2) direct co	onnection: AC 0.116 A (1 A)*	
Overcurrent (alarm 1) direct con	direct connection: AC 0.116 A (10 A)*	
current transformer	r x/5 A: 0.1 x n999 A (10 A)*	
Transformation ratio n	12000 (1)*	
Relative uncertainty in the range of 50/60 Hz	\pm 3 % \pm 2 digit	
Relative uncertainty in the range of 40460 Hz	\pm 5 % \pm 2 digits	
Hysteresis	140% (15 %)*	
Time response		
Start-up delay t	099 s (0.5 s)*	
Response delay t _{on1}	099 s (1 s)*	
Response delay ton2	099 s (0 s)*	
Delay on release toff	099 s (0.1 s)*	
Operating time t _{ae}	≤ 70 ms	
Response time t _{an}	$t_{\rm an} = t_{\rm ae} + t_{\rm on1/2}$	
Recovery time t _b	≤ 300 ms	
Displays, memory		
Display range measured value	AC 0.0116 A x n	
Operating uncertainty in the range of 50/60 Hz	± 3 % ± 2 digit	
	$\pm 5\% \pm 2 \text{ digit}$	
Operating uncertainty in the range of 40460 Hz		
Operating uncertainty in the range of 40460 Hz Measured-value memory for alarm value	data record measured values	

Switching elements					
Number	2 relays, each with 1 changeover contact				
Operating principle		NC/N/O	operation	n (N/O ope	eration)*
Electrical endurance, number of cycles					10000
Contact data acc. to IEC 60947-5-1					
Utilisation category	AC-13	AC-14	DC-12	DC-12	DC-12
Rated operational voltage	230 V	230 V	24 V	110 V	220 V
Rated operational current	5 A	3 A	1 A	0.2 A	0.1 A
Minimum contact load/gold-plated relay	contacts		1 m	A at AC/D	C ≥ 10 V
Environment/EMC					
EMC				IEC	61326-1
Operating temperature				-25	.+55 ℃
Climatic class acc. to IEC 60721					
Stationary use (IEC 60721-3-3)	3K5 (excep	t conden	sation an	d formatio	on of ice)
Transport (IEC 60721-3-2)	2K3 (excep	t conden	sation an	d formatio	on of ice)
Long-time storage (IEC 60721-3-1)	1K4 (excep	t conden	sation an	d formatio	on of ice)
Classification of mechanical conditions IE	C 60721				
Stationary use (IEC 60721-3-3)					3M4
Transport (IEC 60721-3-2)					2M2
Long-time storage (IEC 60721-3-1)					1M3
Connection					
Connection type			рі	ısh-wire t	erminals
Connection properties					
rigid				m² (AWG 2	
flexible without ferrule				m² (AWG 2	
flexible with ferrule		0.21.5 mm ² (AWG 2416)			
Stripping length					10 mm
Opening force					50 N
Test opening, diameter					2.1 mm
Other					
Operating mode			cor	ntinuous o	peration
Position of normal use					any
Degree of protection, internal componen	ts (IEC 60529)			IP30
Degree of protection, terminals (IEC 6052	29)				IP30
Enclosure material				polyca	arbonate
Screw mounting			2 x M4 v	vith mour	
DIN rail mounting acc. to					C 60715
Flammability class					UL94V-0
Documentation number					D00034
Weight					≤ 160 q
_ · J ·					

()* factory setting

Ordering information

Supply voltage ¹⁾ U _S		Туре	Art. No.	
AC	DC	.,,,,	7.1. 6.1.13.	
1672 V, 42460 Hz	9.694 V	CME420-D-1	B 7306 0001	
70300 V, 42460 Hz	70300 V	CME420-D-2	B 7306 0002	

Device version with screw terminals on request.

Accessories

Type designation	Art. No.
Mounting clip for screw mounting (1 piece per device)	B 9806 0008


Dimension diagram XM420


Dimensions in mm

Open the front plate cover in direction of arrow!

Screw mounting

Note: The upper mounting clip must be ordered separately (see ordering information).







Bender GmbH & Co. KG

P.O. Box 1161 • 35301 Gruenberg • Germany Londorfer Strasse 65 • 35305 Gruenberg • Germany Tel.: +49 6401 807-0 • Fax: +49 6401 807-259 E-Mail: info@bender.de • www.bender.de



¹⁾ Absolut values